



**Airsoft Electric Gun**

# M134-A2

## VULCAN MINIGUN

**Handling Cautions And Instruction Manual**



**Metal Casting**




**Limited  
Edition**



## 1 Outlook / Structure of M134-A2 VULCAN MINIGUN

Always set the selector switch to the safe position when you are not firing or during storage

### M134-A2 VULCAN MINIGUN



## 2 Specification


### Data of Automatic Electric Gun

Name	<b>M134-A2 VULCAN MINIGUN</b>  S009M	
Weight	11.65 kg	
Barrel Length	533.4 mm	
Barrel Caliber	6.08 mm	
Pellet Capacity	2000 Rd	
Pellet	6mm BB	
Initial Pellet Speed	105~130m/s	
Battery Type	12V Mini Type	




## 3 Operation

### 1 How to use safety lock



**S : Safety Lock**






**F : Full Auto**

### 2 How to enter the BB pellet

1 Remove the Cap.

2 Insert BB into the entrance.


3 Put the Cap back on






## 3 How to insert battery


1 Remove the screws.




2 Remove the cover and pull out the connector.




3 Connect the battery to the connector.




4 Place the battery into the space.



5 Put the cover back on and tighten the screw.




6 Press the trigger to test the rotation of the barrel. It should turn anti-clockwise.






## 4 How to adjust the Hop-up System

1




2

Pull out the pin.




3

Remove the cover .




4

Adjust the hop up by turning the dial




5

After adjustment turn the barrel to check if the dial is too loose.



6

Put the cover back on and lock it with the two pins.



Turning excessively will adversely affect the trajectory. Stop turning the hop up adjustment dial when pellets shoot horizontally.



Over turning towards the hop up will cause pellets to clog easily. Keep pulling the trigger with clogged pellets will damage the piston and gears.





Be careful with your fingers.




## 5 Gas Injection

1 Put the gas hose into the adapter

2 The procedure is completed



## 6 How to fire



- There are possible cases that no firing occurs after pulling the trigger in the semi auto mode. In this case, do not pull the trigger furiously. Fire 5 to 10 pellets in the full auto mode and then return to the semi auto mode.



- Smell may be generated from the motor for a while when a new air gun is operated, this is the normal operation of the gun.



- The hop up operation may be unstable for 200 to 300 pellets after using silicone oil, this is the normal operation of the gun.

### Cautions on Motor and Battery





Change the battery if the firing cycle becomes slow.  
Give the air gun a rest for 5 to 10 minutes after firing about 500 pellets in order to ensure high durability of the motor and battery.

### When pellets are clogged

If pellets are clogged, remove them and apply a few drops of silicone oil into the chamber from the magazine entrance as shown or spray silicone oil for 0.5 to 1 sec, to obtain smooth continuous firing (Never use CRC-556 or other mineral oil)



## 8 ! WARNING



In no event shall Classic Army or any of our partners be liable for any direct or indirect, special, incidental, or consequential damages in connection with the use of our products.

## 9 For complete product information, dealer locations and technical support, please visit the website of Classic Army Sole Distributors.

**Italy, San Marino Republic, Città del Vaticano, Spain (includes Andorra and Gibraltar) Portugal and Switzerland**

Co. Name: Evolution International S.r.l  
Add.: Via dell' Annunziata n.31, 20121 Milan, Italy  
Tel: (39) 02 25459027  
Fax: (39) 02 25118356  
Email: info@evolution-airsoft.com  
Website: www.evolution-airsoft.com

**Denmark, Sweden, Norway & Finland, France, Germany, Austria, United Kingdom, Poland, Baltic countries, Belgium, Luxembourg, the Czech Republic and Slovakia**

Co. Name: ActionSportGames A/S  
Add.: Bakkegaardsvej 304, DK-3050 Humlebaek, Denmark  
Tel: (45) 89 28 18 88  
Fax: (45) 49 19 31 60  
Email: sales@actionsportgames.com  
Website: http://www.actionsportgames.com/

**The United States of America**

Co. Name: Spartan Imports, Inc.  
Add.: 213 Lawrence Avenue, S. San Francisco, California, USA 94080  
Tel: (1) 650 589 5501  
Fax: (1) 650 589 5552  
Email: info@spartanimports.com  
Website: http://www.spartanimports.com/

**Taiwan**

Co. Name: F-Links Int'l Enterprise Co. Ltd.  
Add.: No.3 Lane 62, Jianguo 1st Rd., Lingya District, Kaohsiung City 802, Taiwan, R.O.C.  
Tel: (886) 7-710 0198  
Fax: (886) 7-710 0398  
Email: kssa.kssa@msa.hinet.net  
Website: http://www.soloman.com.tw/

**Japan**

Co. Name: Union Fire Company (UFC)  
Add.: 542-0067, 6-10-101 · MATSUYAMACHI, CHUO-KU, OSAKA, JAPAN  
Tel: +81-6-4304-7750  
Fax: +81-6-4304-7799  
Email: ufctrading@ufc-web.com  
Website: http://www.ufc-web.com/

**Ukraine**

Co. Name: Vizantiya-1  
Add.: Kiev Av. A. Navoi, 76, Ukraine  
Tel: (380)44 4084369  
Fax: (380)44 4080633  
Email: vizantiya\_1@svitonline.com  
Website: http://www.militarist.com.ua/





[www.classicarmy.com](http://www.classicarmy.com) [info@classicarmy.com](mailto:info@classicarmy.com)



**WARNING**

- FOR AGE 18 OR ABOVE.
- PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE USE.  
MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY.
- USER SHOULD OBEY TO THE LAWS REGARDING THE USAGE AND OWNERSHIP  
OF AIRSOFT ELECTRIC GUNS.
- FACIAL PROTECTION IS REQUIRED.

Produced By Classic Army, Hong Kong

2009-12-21 Edition 1 Yick Funa Ind. Int'l Ltd. All Rights Reserved

Ad.max.67